

Hydro Solo-S

Installation and operating instructions

GB D F S FIN DK RU



(GB) Declaration of Conformity

We, Grundfos, declare under our sole responsibility that the products Hydro Solo-S, to which this declaration relates, are in conformity with these Council directives on the approximation of the laws of the EC member states:

- Machinery Directive (2006/42/EC).
Standards used: EN 809: 1998 and EN 60204-1: 2006.
- Low Voltage Directive (2006/95/EC).
Standards used: EN 60335-1: 2002 and EN 60335-2-41: 2003.
- EMC Directive (2004/108/EC).
Standards used: EN 61000-6-2: 2005 and EN 61000-6-3: 2007.
- Pressure Equipment Directive (97/23/EC).
Standard used: EN 13831: 2007.

(F) Déclaration de Conformité

Nous, Grundfos, déclarons sous notre seule responsabilité, que les produits Hydro Solo-S, auxquels se réfère cette déclaration, sont conformes aux Directives du Conseil concernant le rapprochement des législations des Etats membres CE relatives aux normes énoncées ci-dessous :

- Directive Machines (2006/42/CE).
Normes utilisées : EN 809: 1998 et EN 60204-1: 2006.
- Directive Basse Tension (2006/95/CE).
Normes utilisées : EN 60335-1 : 2002 et EN 60335-2-41 : 2003.
- Directive Compatibilité Electromagnétique CEM (2004/108/CE).
Normes utilisées : EN 61000-6-2: 2005 et EN 61000-6-3: 2007.
- Directive concernant les équipements sous pression (97/23/CE).
Norme utilisée : EN 13831: 2007.

(FIN) Vaatimusten mukaisuusvakuutus

Me, Grundfos, vakuutamme omalla vastuullamme, että tuotteet Hydro Solo-S, joita tämä vakuutus koskee, ovat EY:n jäsenvaltioiden lainsäädännön yhdenmukaistamiseen tähtäävien Euroopan neuvoston direktiivien vaatimusten mukaisia seuraavasti:

- Konedirektiivi (2006/42/EY).
Sovellettavat standardit: EN 809: 1998 ja EN 60204-1: 2006.
- Pienjännittdirektiivi (2006/95/EY).
Sovellettavat standardit: EN 60335-1: 2002 ja EN 60335-2-41: 2003.
- EMC-direktiivi (2004/108/EY).
Sovellettavat standardit: EN 61000-6-2: 2005 ja EN 61000-6-3: 2007.
- Painelaitteita koskeva direktiivi (97/23/EY).
Sovellettu standardi: EN 13831: 2007.

(RU) Декларация о соответствии

Мы, компания Grundfos, со всей ответственностью заявляем, что изделия Hydro Solo-S, к которым относится настоящая декларация, соответствуют следующим Директивам Совета Евросоюза об унификации законодательных предписаний стран-членов ЕС:

- Механические устройства (2006/42/EC).
Применявшиеся стандарты: EN 809: 1998 и EN 60204-1: 2006.
- Низковольтное оборудование (2006/95/EC).
Применявшиеся стандарты: EN 60335-1: 2002 и EN 60335-2-41: 2003.
- Электромагнитная совместимость (2004/108/EC).
Применявшиеся стандарты: EN 61000-6-2: 2005 и EN 61000-6-3: 2007.
- Директива по оборудованию, работающему под давлением (97/23/EC).
Применявшийся стандарт: EN 13831: 2007.

(D) Konformitätserklärung

Wir, Grundfos, erklären in alleiniger Verantwortung, dass die Produkte Hydro Solo-S, auf die sich diese Erklärung bezieht, mit den folgenden Richtlinien des Rates zur Angleichung der Rechtsvorschriften der EU-Mitgliedsstaaten übereinstimmen:

- Maschinenrichtlinie (2006/42/EG).
Normen, die verwendet wurden: EN 809: 1998 und EN 60204-1: 2006.
- Niederspannungsrichtlinie (2006/95/EG).
Normen, die verwendet wurden: EN 60335-1: 2002 und EN 60335-2-41: 2003.
- EMV-Richtlinie (2004/108/EG).
Normen, die verwendet wurden: EN 61000-6-2: 2005 und EN 61000-6-3: 2007.
- Richtlinie über Druckeinrichtungen (97/23/EG).
Norm, die verwendet wurde: EN 13831: 2007.

(S) Försäkran om överensstämmelse

Vi, Grundfos, försäkrar under ansvar att produkterna Hydro Solo-S, som omfattas av denna försäkran, är i överensstämmelse med rådets direktiv om inbördes närmande till EU-medlemsstaternas lagstiftning, avseende:


- Maskindirektiv (2006/42/EG).
Tillämpade standarder: EN 809: 1998 och EN 60204-1: 2006.
- Lågspänningsdirektiv (2006/95/EG).
Tillämpade standarder: EN 60335-1: 2002 och EN 60335-2-41: 2003.
- EMC-direktiv (2004/108/EG).
Tillämpade standarder: EN 61000-6-2: 2005 och EN 61000-6-3: 2007.
- Direktiv för tryckutrustning (97/23/EG).
Tillämpad standard: EN 13831: 2007.

(DK) Overensstemmelseserklæring

Vi, Grundfos, erklærer under ansvar at produkterne Hydro Solo-S som denne erklæring omhandler, er i overensstemmelse med disse af Rådets direktiver om indbyrdes tilnærmelse til EF-medlemsstaternes lovgivning:

- Maskindirektiv (2006/42/EF).
Anvendte standarder: EN 809: 1998 og EN 60204-1: 2006.
- Lavspændingsdirektiv (2006/95/EF).
Anvendte standarder: EN 60335-1: 2002 og EN 60335-2-41: 2003.
- EMC-direktiv (2004/108/EF).
Anvendte standarder: EN 61000-6-2: 2005 og EN 61000-6-3: 2007.
- Trykudstyrsdirektiv (97/23/EF).
Anvendt standard: EN 13831: 2007.

Bjerringbro, 25th January 2010



Jan Strandgaard
Technical Director

Hydro Solo-S

Installation and operating instructions	4	GB
Montage- und Betriebsanleitung	10	D
Notice d'installation et d'entretien	17	F
Monterings- och driftsinstruktion	23	S
Asennus- ja käyttöohjeet	29	FIN
Monterings- og driftsinstruktion	35	DK
Руководство по монтажу и эксплуатации	41	RU

CONTENTS

	Page
1. General description	4
1.1 Applications	4
1.2 Operating conditions	4
2. System configuration	5
2.1 Function	5
3. Installation	5
3.1 Location	5
3.2 Pipe connection	5
3.3 Priming	5
3.4 Electrical connection	6
3.5 Direction of rotation	6
3.6 Motor protection	6
4. Settings	7
4.1 Pre-charge pressure	7
4.2 Cut-in pressure	7
4.3 Cut-out pressure	8
4.4 Differential pressure	8
5. Fault finding chart	9
6. Disposal	9

Before beginning installation procedures, these installation and operating instructions should be studied carefully. The installation and operation should also be in accordance with local regulations and accepted codes of good practice.



The use of this product requires experience with and knowledge of the product.

Persons with reduced physical, sensory or mental capabilities must not use this product, unless they are under supervision or have been instructed in the use of the product by a person responsible for their safety. Children must not use or play with this product.



1. General description

1.1 Applications

The Grundfos single-pump booster set is designed for water boosting and transfer in small blocks of flats, farms, cottages, etc. where the water requirements are relatively low.




Fig. 1

Water temperature	Maximum +60°C
System pressure	
CR 1-4, 1-7, 1-10	Maximum 6 bar
CR 1-13, 1-17	Maximum 10 bar
CR 3-4, 3-7, 3-10	Maximum 6 bar
CR 3-12, 3-15	Maximum 10 bar
CR 5-3, 5-4, 5-5, 5-8	Maximum 6 bar
CR 5-10, 5-15	Maximum 10 bar
Flow, Q	1-8 m ³ /h

TM02 4127 4901

2. System configuration




Fig. 2

Pos.	Description
1	Pump
2	Diaphragm tank
3	Pressure switch
4	Pressure gauge
5	Discharge pipe, brass
6	Isolating valve

2.1 Function

The booster set is cut in and out by means of the pressure switch. When water is consumed, this is tapped from the diaphragm tank.

Then the pressure drops to a preset pump cut-in pressure and the pump starts.

When the water consumption falls, the discharge pressure rises. The pump stops when the cut-out pressure preset on the pressure switch is reached.

TM02 2587 2702

3. Installation

3.1 Location

The booster set should be installed and electrically connected in accordance with local regulations.

The booster set should be located in a well ventilated room. The motor requires an adequate air supply to prevent overheating.

3.2 Pipe connection

Arrows on the pump base show the direction of flow of water through the pump.

The pipes connected to the booster set must be adequately sized.

Caution: The booster set has no non-return valve. A non-return/foot valve must be fitted to the suction pipe.

3.3 Priming

Do not start the pump until it has been filled with liquid.

Closed systems or open systems where the liquid level is above the pump inlet:

1. Close the isolating valve on the discharge pipe.
2. Remove the priming plug (pos. 1) from the pump head. See fig. 3.
3. Gradually open the isolating valve on the suction pipe until a steady stream of liquid runs out the priming port.
4. Refit the priming plug and tighten securely.
5. Open the isolating valve(s).




Fig. 3

Pos.	Description
1	Priming plug
2	Drain plug
3	Drain plug/bypass valve

TM02 6431 0603

Open systems where the liquid level is below the pump inlet:

1. Close the isolating valve on the discharge pipe.
2. Slacken the small screw of the bypass valve (pos. 3) and pull it out against stop. See fig. 3.
3. Remove the priming plug (pos. 1) from the pump head.
4. Pour liquid through the priming hole (use a funnel) until the suction pipe and pump are completely filled with liquid. The liquid can be seen in the priming hole.
5. Tighten the screw of the bypass valve.
6. Refit the priming plug and tighten securely.
7. Open the isolating valve(s).

3.4 Electrical connection

The electrical connection should be carried out in accordance with local regulations.



Never make any connections in the terminal box or in the pressure switch unless the electricity supply has been switched off.

The operating voltage and frequency are marked on the nameplate. Please make sure that the motor is suitable for the electricity supply on which it will be used.

3.5 Direction of rotation

The direction of rotation of the pump is counter-clockwise when seen from the top.

If the direction of rotation is wrong, switch off the electricity supply and interchange two phases of the mains supply.

3.6 Motor protection

Single-phase motors incorporate thermal protection and consequently require no additional motor protection.

Three-phase motors must be connected to a motor starter in accordance with local regulations.

In order to protect the motor against quick and slow overload, it must be connected to an external thermomagnetic relay, type GV2-ME. See fig. 4.




Fig. 4

4. Settings

All pressure settings are described in the following sections.

Figure 5 shows the relationship between system/cut-out pressure, differential pressure, cut-in pressure and pre-charge pressure of the diaphragm tank.




Fig. 5

4.1 Pre-charge pressure

The tank pre-charge pressure has been factory-set to 0.9 x cut-in pressure (see section 4.2 *Cut-in pressure*) or to 2 bar.

If not otherwise stated, the factory-set cut-in pressure is 0,5 x maximum pump pressure.

If the cut-in pressure is changed, the tank pre-charge pressure must also be adjusted to ensure optimum operation.

Calculate the pre-charge pressure as follows:

Pre-charge pressure = 0.9 x cut-in pressure.

The pre-charge pressure must be measured in a pressure-less system.

It is recommended to use nitrogen gas for precharging.

Checking of tank pre-charge pressure:

To ensure optimum operation of the system, i.e. frequency of starts and stops, it is recommended to check the pre-charge pressure of the diaphragm tank at regular intervals (at least once a year).

4.2 Cut-in pressure

The cut-in pressure is set on the pressure switch by means of the adjusting screws for cut-out pressure and differential pressure.




Fig. 6

Pos.	Description
1	Cut-out pressure screw
2	Differential pressure screw

Cut-out pressure: The pump stops.

Differential pressure: Pressure drop – the pump restarts.

The cut-in pressure can be calculated as cut-out pressure – differential pressure.

Example:

Cut-out pressure	5 bar
Differential pressure	1.5 bar
Cut-in pressure	3.5 bar

TM02 6437 0603

TM02 6460 0803

4.3 Cut-out pressure

Figure 7 shows the curve for cut-out pressure setting.




Fig. 7

A = Number of turns of the cut-out pressure screw (pos. 1), fig. 6.

4.4 Differential pressure

Proceed as follows (see fig. 8 or 9):

1. Mark the cut-out pressure on the axis to the left and the differential pressure on the axis to the right.
2. Draw a line between the two points.
3. Read the value on the number line. This value is the number of turns of the differential pressure screw (pos. 2), fig. 6.

Example:

The example in fig. 8 shows:

Cut-out pressure = 5 bar.

Differential pressure = 1.5 bar.

The number line from 0 to 9 is intersected at a value of 4.5, i.e. that the differential pressure screw must be turned 4.5 times.

Nomogram for differential pressure 2 to 6 bar




Fig. 8

Nomogram for differential pressure 4 to 12 bar




Fig. 9

Note: If the differential pressure has been set to a value which is higher than the cut-out pressure, the booster set cannot start. Set the differential pressure to a lower value (turn the differential pressure screw clockwise).

5. Fault finding chart



Never make any connections in the terminal box or in the pressure switch unless the electricity supply has been switched off.

GB

Fault	Cause
1. Motor does not run when started.	a) Supply failure. b) Motor protection has tripped out (in the case of single-phase operation, the motor starts automatically after a short time). c) Main contacts in starter are not making contact or the magnetic coil is faulty (three-phase operation).
2. Motor starter overload has tripped out (trips out immediately when supply is switched on).	a) Contacts in starter overload are faulty (three-phase operation). b) Cable connection is loose or faulty. c) Motor winding is defective. d) Pump is mechanically blocked. e) Starter overload setting too low (three-phase operation).
3. Motor starter overload trips out occasionally (three-phase operation).	a) Starter overload setting too low. b) Periodic supply failure. c) Low voltage at peak times.
4. Booster set capacity is not constant.	a) Suction pipe is too small for capacity of booster set. b) Insufficient water is available at the pump inlet. c) Water level is too low. d) Suction pipe is partly blocked by impurities.
5. Booster set runs but gives no water.	a) Suction pipe is blocked by impurities. b) Leakage in suction pipe. c) Air in suction pipe or booster set. d) Non-return/foot valve is blocked in closed position.
6. Pump starts and stops too frequently.	a) Pressure switch setting is incorrect. b) Tank pre-charge pressure is incorrect. c) Non-return/foot valve in suction pipe does not shut tight. d) Leakage in diaphragm of tank. Lower the tank pre-charge pressure. If the diaphragm leaks, water will run out the valve when the booster set is operating.

6. Disposal

This product or parts of it must be disposed of in an environmentally sound way:

1. Use the public or private waste collection service.
2. If this is not possible, contact the nearest Grundfos company or service workshop.

Argentina

Bombas GRUNDFOS de Argentina S.A.
Ruta Panamericana km. 37.500 Lote 34A
1619 - Garin
Pcia. de Buenos Aires
Phone: +54-3327 414 444
Telefax: +54-3327 411 111

Australia

GRUNDFOS Pumps Pty. Ltd.
P.O. Box 2040
Regency Park
South Australia 5942
Phone: +61-8-8461-4611
Telefax: +61-8-8340 0155

Austria

GRUNDFOS Pumpen Vertrieb Ges.m.b.H.
Grundfosstraße 2
A-5002 Grödig/Salzburg
Tel.: +43-6248-883-0
Telefax: +43-6246-883-30

Belgium

N.V. GRUNDFOS Bellux S.A.
Boomsstedenweg 81-83
B-2630 Aartselaar
Tel.: +32-3-870 7300
Téléphone: +32-3-870 7301

Belorussia

Представителство ГРУНДФОС в
Минск
220123, Минск,
ул. В. Хоружей, 22, оф. 1105
Тел.: +(37517) 233 97 65,
Факс: +(37517) 233 97 69
E-mail: herdzog_minsk@mail.ru

Bosnia/Herzegovina

GRUNDFOS Sarajevo
Trg Heroja 16,
BIH-71000 Sarajevo
Phone: +387 33 713 290
Telefax: +387 33 659 079
e-mail: grundfos@bih.net.ba

Brazil

Mark GRUNDFOS Ltda.
Av. Humberto de Alencar Castelo Branco,
630
CEP 09850 - 300
São Bernardo do Campo - SP
Phone: +55-11 4393 5533
Telefax: +55-11 4343 5015

Bulgaria

GRUNDFOS Pumpen Vertrieb
Representative Office - Bulgaria
Bulgaria, 1421 Sofia
Lozenetz District
105-107 Arsenalski Blvd.
Phone: +359 2963 3620, 2963 5653
Telefax: +359 2963 1305

Canada

GRUNDFOS Canada Inc.
2941 Brighton Road
Oakville, Ontario
L6H 6C9
Phone: +1-905 829 9533
Telefax: +1-905 829 9512

China

GRUNDFOS Pumps (Shanghai) Co. Ltd.
51 Floor, Raffles City
No. 268 Xi Zang Road. (M)
Shanghai 200001
PRC
Phone: +86-021-612 252 22
Telefax: +86-021-612 253 33

Croatia

GRUNDFOS CROATIA d.o.o.
Cebini 37, Buzin
HR-10010 Zagreb
Phone: +385 1 6595 400
Telefax: +385 1 6595 499
www.grundfos.hr

Czech Republic

GRUNDFOS s.r.o.
Čajkovského 21
779 00 Olomouc
Phone: +420-585-716 111
Telefax: +420-585-716 299

Denmark

GRUNDFOS DK A/S
Martin Bachs Vej 3
DK-8850 Bjerringbro
Tlf.: +45-87 50 50 50
Telefax: +45-87 50 51 51
E-mail: info_GDK@grundfos.com
www.grundfos.com/DK

Estonia

GRUNDFOS Pumps Eesti OÜ
Peterburi tee 92G
11415 Tallinn
Tel.: + 372 606 1690
Fax: + 372 606 1691

Finland

OY GRUNDFOS Pumput AB
Mestariintie 11
FIN-01730 Vantaa
Phone: +358-3066 5650
Telefax: +358-3066 5650

France

Pompes GRUNDFOS Distribution S.A.
Parc d'Activités de Chesnes
57, rue de Malacombe
F-38290 St. Quentin Fallavier (Lyon)
Tel.: +33-4 74 82 15 15
Téléphone: +33-4 74 94 10 51

Germany

GRUNDFOS GMBH
Schillerstr.: 33
40699 Erkrath
Tel.: +49-(0) 211 929 69-0
Telefax: +49-(0) 211 929 69-3799
e-mail: info@grundfos.de
Service in Deutschland:
e-mail: kundendienst@grundfos.de

Greece

GRUNDFOS Hellas A.E.B.E.
20,th km. Athinon-Markopoulou Av.
P.O. Box 71
GR-19002 Peania
Phone: +0030-210-66 83 400
Telefax: +0030-210-66 46 273

Hong Kong

GRUNDFOS Pumps (Hong Kong) Ltd.
Unit 1, Ground floor
Siu Wai Industrial Centre
29-33 Wing Hong Street &
68 King Lam Street, Cheung Sha Wan
Kowloon
Phone: +852-27861706 / 27861741
Telefax: +852-27858664

Hungary

GRUNDFOS Hungária Kft.
Park u. 8
H-2045 Törökbalánt,
Phone: +36-23 511 110
Telefax: +36-23 511 111

India

GRUNDFOS Pumps India Private Limited
118 Old Mahabaliapuram Road
Thoraipakkam
Chennai 600 096
Phone: +91-44 2496 6800
Telefax: +91-44 2496 6800

Indonesia

PT GRUNDFOS Pompa
Jl. Rawa Sumur III, Blok III / CC-1
Kawasan Industri, Pulogadung
Jakarta 13930
Phone: +62-21-460 6909
Telefax: +62-21-460 6910 / 460 6901

Ireland

GRUNDFOS (Ireland) Ltd.
Unit A, Merrywell Business Park
Ballymunt Road Lower
Dublin 12
Phone: +353-1-4089 800
Telefax: +353-1-4089 830

Italy

GRUNDFOS Pompe Italia S.r.l.
Via Gran Sasso 4
I-20060 Truccazzano (Milano)
Tel.: +39-02-95838112
Telefax: +39-02-95309290 / 95838461

Japan

GRUNDFOS Pumps K.K.
Gotanda Metation Bldg., 5F,
5-21-15, Higashi-gotanda
Shiagawa-ku, Tokyo
141-0022, Japan
Phone: +81 35 448 1391
Telefax: +81 35 448 9619

Korea

GRUNDFOS Pumps Korea Ltd.
6th Floor, Aju Building 679-5
Yeoksam-dong, Kangnam-ku, 135-916
Seoul, Korea
Phone: +82-2-5317 600
Telefax: +82-2-5633 725

Latvia

SIA GRUNDFOS Pumps Latvia
Deglava biznesa centrs
Augusta Deglava iela 60, LV-1035, Rīga,
Tālr.: + 371 714 9640, / 749 641
Fakss: + 371 914 9646

Lithuania

GRUNDFOS Pumps UAB
Smolensko g. 6
LT-03201 Vilnius
Tel.: + 370 52 395 430
Fax: + 370 52 395 431

Malaysia

GRUNDFOS Pumps Sdn. Bhd.
7 Jalan Peguam UI/25
Glenmarie Industrial Park
40150 Shah Alam
Selangor
Phone: +60-3-5569 2922
Telefax: +60-3-5569 2866

México

Bombas GRUNDFOS de México S.A. de
C.V.
Boulevard Tlaco No. 15
Parque Industrial Stiva Aeropuerto
Apodaca, N.L. 66600
Phone: +52-81-8144 4000
Telefax: +52-81-8144 4010

Netherlands

GRUNDFOS Netherlands
Veluwezoom 35
1326 AE Almere
Postbus 22015
1302 CA ALMERE
Tel.: +31-86-478 6336
Telefax: +31-86-478 6332
e-mail: info_gnl@grundfos.com

New Zealand

GRUNDFOS Pumps NZ Ltd.
17 Beatrice Timsey Crescent
North Harbour Industrial Estate
Albany, Auckland
Phone: +64-9-415 3240
Telefax: +64-9-415 3250

Norway

GRUNDFOS Pumper A/S
Strømsveien 344
Postboks 235, Leirdal
N-1011 Oslo
Tlf.: +47-22-92 40 70
Telefax: +47-22-92 31 50

Poland

GRUNDFOS Pompy Sp. z o.o.
ul. Klonowa 23
Baranowo k. Poznania
Pl.-62-081 Przewmierowo
Tel: (+48-61) 650 13 00
Fax: (+48-61) 650 13 50

Portugal

Bombas GRUNDFOS Portugal, S.A.
Rua Calvet de Magalhães, 241
Apartado 1079
P-2770-155 Paço de Arcos
Tel.: +351-21-440 76 00
Telefax: +351-21-440 76 90

România

GRUNDFOS Pompa România SRL
Bd. Biruintei, nr 103
Pantelimon county Ilofov
Phone: +40 21 200 4100
Telefax: +40 21 200 4101
E-mail: romania@grundfos.ro

Russia

ООО Грундфос
Прессия, 109544 Москва, ул. Школьная 39
Тел. +7(495) 737 30 00, 564 88 00
Факс +7(495) 737 75 36, 564 88 11
E-mail grundfos.moscow@grundfos.com

Serbia

GRUNDFOS Predstavništvo Beograd
Dr. Milutina Ivkovića 2a/29
YU-11000 Beograd
Phone: +381 11 26 47 877 / 11 26 47 496
Telefax: +381 11 26 48 340

Singapore

GRUNDFOS (Singapore) Pte. Ltd.
24 Tuas West Road
Jurong Town
Singapore 638381
Phone: +65-6865 1222
Telefax: +65-6861 8402

Slovenia

GRUNDFOS PUMPEN VERTRIEB
Ges.m.b.H.,
Pordružnica Ljubljana
Štandrova 8b, SI-1231 Ljubljana-Črnuče
Phone: +386 1 568 0610
Telefax: +386 1 568 0619
E-mail: slovenia@grundfos.si

Spain

Bombas GRUNDFOS España S.A.
Camino de la Fuentequilla, s/n
E-28110 Algete (Madrid)
Tel.: +34-91-848 8800
Telefax: +34-91-828 0465

Sweden

GRUNDFOS AB
Box 533 (Lunnagårdsgatan 6)
431 24 Molndal
Tel.: +46(0)771-32 23 00
Telefax: +46(0)31-331 94 60

Switzerland

GRUNDFOS Pumpen AG
Bruggacherstrasse 10
CH-8117 Fallanden/ZH
Tel.: +41-1-806 8111
Telefax: +41-1-806 8115

Taiwan

GRUNDFOS Pumps (Taiwan) Ltd.
7 Floor, 219 Min-Chuan Road
Taichung, Taiwan, R.O.C.
Phone: +886-4-2305 0868
Telefax: +886-4-2305 0878

Thailand

GRUNDFOS (Thailand) Ltd.
92 Chaloom Phrakiat Rama 9 Road,
Dokmai, Pravej, Bangkok 10250
Phone: +66-2-725 8999
Telefax: +66-2-725 8998

Turkey

GRUNDFOS POMPA San. ve Tic. Ltd. Sti.
Gebze Organize Sanayi Bölgesi
İhsan dede Caddesi,
2. yol 200. Sokak No. 204
41490 Gebze/Kocaeli
Phone: +90 - 262-679 7979
Telefax: +90 - 262-679 7905
E-mail: satis@grundfos.com

Ukraine

ТОВ ГРУНДФОС УКРАЇНА
01010 Київ, вул. Московська 85,
Тел.: (+38 044) 390 40 50
Факс: (+38 044) 390 40 59
E-mail: ukraine@grundfos.com

United Arab Emirates

GRUNDFOS Gulf Distribution
P.O. Box 16768
Jebel Ali Free Zone
Dubai
Phone: +971-4- 8815 166
Telefax: +971-4-8815 136

United Kingdom

GRUNDFOS Pumps Ltd.
Grovebury Road
Leighton Buzzard/Beds. LU7 8TL
Phone: +44-1525-850000
Telefax: +44-1525-850011

U.S.A.

GRUNDFOS Pumps Corporation
17100 West 118th Terrace
Olathe, Kansas 66061
Phone: +1-913-227-3400
Telefax: +1-913-227-3500

Uzbekistan

Представителство ГРУНДФОС в
Ташкенте
700000 Ташкент ул.Усмана Носира 1-й
тулик 5
Телефон: (3712) 55-68-15
Факс: (3712) 53-36-35

3C0370 0210	20
Repl. 3C0370 1206	

The name Grundfos, the Grundfos logo, and the payoff Be–Think–Innovate are registered trademarks owned by Grundfos Management A/S or Grundfos A/S, Denmark. All rights reserved worldwide.
